



Cutting

- Cut 1 back to the fold
- Cut 1 front to the fold
- Cut strips of fabric along the edge (lengthwise) to the correct width of your binder attachment. I've used 4.2cm width



Sewing

- Sew shoulder seam on one side, right sides together
- Sew the binding around the arm hole on the side that is joined.

- Sew the binding around the neck
- Sew the second shoulder closed
- Sew binding around the second armhole
- Sew the back to the front, right sides together
- Overlock the hem
- Hem
- Dethread and neaten
- Steam press
- Enjoy